

Water Cooler Accessories

Drip tray options



3 litre overflow kit connects the drip tray to a 3 litre alarmed overflow container. The container has a tap to empty without removing it. Factory fitted or self-installed.



10 litre overflow system with alarm to signal when full. Factory fitted.




Mains drainage system connecting the drip tray to the waste. Factory installed.



A pumped main drainage system pumps the waste water from the drip tray over a distance of 100m and a rise of 5m. Factory installed.

SIP Automatic Sanitising



SIP Neo3 Automatically Sanitises your Cooler! The resulting high Hygiene level protects your customers health, and SIP Sleep mode reduces their Electricity bill.

Fixing the cooler to wall and floor



A strong metal cowling to fix the water cooler to the wall and floor. Self-installed (also available for fountains).



Wall bracket to fit all coolers and fountains. Self-installed.

POU Installation rail and filters



Installation rail with filter. Includes compression fitting. 1-Micron Green filter. Water block. Copper pressure reducing valve and non-return valve.



Green filter housing with carbon block filter and nanofilter. Filter housing. 1-Micron Green filter carbon block candle. Nano filter candle, high viral, cyst, pharma performance.

Conversion kit



Easily convertible from bottled to POU. The bottled top includes Spill Guard leak protection.